

## Pioneer DC Plus Instructions for Releasing Clutch

The Pioneer DC Plus features a ratchet system which makes the tension pulling much easier.

Step 1: Before pulling tension, place the linear gripper in the 1 o'clock position as shown below.



Step 2: After you have pulled tension, you will see that the linear gripper has rotated.



Step 3: Before you lift the bar, you must first locate the clutch and lower it with your finger and then you lift up the bar and allow the string to be released from the gripper.

